



↑Pay
SMART
PAYMENT TERMINAL




↑Pay P5
User Manual
V2025

Table of Contents

Click on a title to take you to its page!

01.	Terminal Diagram	3
02.	System Settings	4
	Power On & Unlock	
	Connect to Wifi	
	Close Current App	
	Move CodePay App	
	Adjust QR Code on Receipt	
	Update Timezone	
03.	Transactions	8
	Credit Sale	
	Debit Sale	
	Cash Sale	
	Card Sale	
	Dual Pricing	
	Manual Key-in	
04.	Tip Adjustment (Add Tip)	11
	Method 1	
	Method 2	
05.	Void Transaction	12
	Method 1	
	Method 2	
06.	Batch Close	13
07.	Reprint Receipt	14
08.	Refund	15
09.	Report	16
10.	Employee ID	17

Terminal Diagram



- 1 Thermal Paper Cabin
- 2 NFC Recognition Area
- 3 Camera (Back)
- 4 Receipt Dispenses from Here
- 5 Magnetic Card Reader
- 6 Hold to Dispense Receipt Paper
- 7 USB-C Charging Port
- 8 Power Button
- 9 IC Card Slot


System Settings

»» Power On & Unlock

1. Turn on the device.
2. Swipe up from the bottom of the screen to unlock.


»» Connect to Wi-Fi

1. Open the **Settings** app.
2. Tap **Network & Internet**.
3. Select **Wi-Fi** and toggle it ON.
4. Choose your Wi-Fi network.
5. Enter the password, and tap the **checkmark (✓)** to connect.
6. Tap the ● button at the bottom center to return to the home screen.



»» Close Current App


1. On the home screen, tap the **■ icon** (bottom right corner).
2. A list of open apps will appear.
3. Swipe up on the app you want to close.
4. Repeat if multiple related apps are open.
5. Once the app is fully closed, return to the home screen → click **CodePay** app.



Tip: Closing the app ensures updates or changes apply properly.


»» Move Codepay App

1. Unlock the device by swiping upward from the bottom of the screen.
2. Touch and hold the **CodePay** icon, then drag it away from the current home screen page to reposition or remove it.



» Adjust QR Code on Receipt

1. Tap the **≡ icon** (top-left corner).
2. Select **Settings**.
3. Enter the Verification of Administrator password → Tap **OK**.
4. Choose **General**.
5. Tap **Receipt**.
6. Turn ON/OFF the **QR Code** option.




» Update Timezone

1. Unlock the device by swiping up from the bottom of the screen.
2. Open the **Settings** app.
3. Go to **System** → **Date & Time**.
4. Change the time zone as needed.
5. If no changes are made, the system time zone will remain set to **EST** by default.
6. To manually update the time zone, toggle **Time zone off**, select the desired time zone, then toggle **Time zone back on** to resume automatic synchronization.
7. Turn on the following options:
 - Use network-provided time
 - Use network-provided time zone
 - Use 24-hour format, or use the local default 12-hour (AM/PM) format
8. Press the ● button at the bottom center to exit Settings.

Transactions


»» Credit Sale

1. Open app **CodePay**.
2. Enter the transaction amount.
3. Choose **Credit** for the payment.
4. Confirm the transaction.
5. The customer inserts, taps, or swipes their card.
6. After approval, Merchant copy receipt prints automatically.
7. Print the Customer copy receipt or bypass.



»» Debit Sale

1. Open app **CodePay**.
2. Enter the transaction amount.
3. Choose **Debit** for the payment.
4. Confirm the transaction.
5. The customer inserts, taps, or swipes their card.
6. Enter **PIN**.
7. After approval, Merchant copy receipt prints automatically.
8. Print the Customer copy receipt or bypass.



»» Cash Sale

1. Open app **CodePay**.
2. Enter the transaction amount.
3. Choose **Cash** for the payment.
4. Confirm the transaction.
5. After approval, Merchant copy receipt prints automatically.
6. Print the Customer copy receipt or bypass.

»» Card Sale

1. Open app **CodePay**.
2. Enter the transaction amount.
3. Choose **Card** for the payment.
4. Confirm the transaction.
5. The customer inserts, taps, or swipes their card.
6. After approval, Merchant copy receipt prints automatically.
7. Print the Customer copy receipt or bypass.

»» Dual Pricing

1. Enter the **transaction amount**.
2. Choose **Credit** for Dual Pricing sale.
3. Confirm Credit (fee already included).
4. The customer inserts, taps, or swipes their card.
5. After approval, Merchant copy receipt prints automatically.
6. Print the Customer copy receipt or bypass.

»» Manual Key-in

1. Enter the **transaction amount** → tap **Credit**.
2. Confirm the amount press **Charge**.
3. When prompted, select **Manual Entry**.
4. Enter the card number, expiration date, and bypass CVV if required.
5. Tap **Confirm** to process the transaction.
6. After approval, Merchant copy receipt prints automatically.
7. Print the Customer copy receipt or bypass.



Tip Adjustment (Add Tip)

» Method 1

1. Tap the **≡ icon** (top left corner).
2. Select **Transactions**.
3. Choose the transaction you want to adjust.
4. Tap **Tip Adjustment** at the bottom of the screen.
5. Enter the tip amount → tap **Done**.



» Method 2

1. Tap the **⌘ icon** (top right corner).
2. Select **Tip Adjustments**.
3. Enter the transactions number.
4. Enter the tip amount → tap **Done**.

Void Transaction

» Method 1

1. Tap the **≡ icon** (top left corner).
2. Select **Transactions**.
3. Select the transaction you want to void.
4. Tap **Void Transaction** at the bottom of the screen.
5. Enter the Verification of Administrator password → Tap **OK**.
6. After approval, the receipt prints automatically.




» Method 2

1. Tap the **⌘ icon** (top right corner).
2. Select **Void**.
3. Enter the **original transaction receipt number**.
4. Confirm the details and press **VOID**.
5. Enter the Verification of Administrator password → Tap **OK**.
6. After approval, the receipt prints automatically.

Batch Close

» Batch Close


1. Tap the **≡ icon** (top left corner).
2. Select **Batch Close**.
3. Tap **Close Batch Now**.
4. Choose statement of batch then tap **OK**.
5. After approval, the receipt prints automatically.



Reprint Receipt

» Reprint Receipt

1. Tap the **≡ icon** (top left corner).
2. Select **Transaction**.
3. Choose the transaction you want to reprint.
4. Tap the **printer icon** (top right corner).
5. Continue to print receipt → tap **OK**.



Refund

» Refund


1. Open app **CodePay**.
2. Tap the  **icon** (top right corner) then select **Refund**.
3. Unreferenced:
 - Enter the **refund amount** and tap OK.
4. By reference:
 - Enter the **original transaction receipt number** and **confirm the refund amount**.
 - Select **All** to refund the full amount, then tap **Refund**.
5. Enter the Verification of Administrator password → Tap **OK**.
6. After approval, the receipt prints automatically.



Report

» Report

1. Tap the **≡ icon** (top left corner).
2. Select **Report**.
3. Tap the **printer icon** (top right corner) if need to print report.
4. To view past reports, select **History** and choose the desired date.



Employee ID

» Employee ID

1. Enter the **transaction amount**.
2. Choose **Credit** or **Debit**.
3. Confirm **Credit** or **Debit** payment.
4. The option for Employee ID is under the tip options.
5. Enter Employee ID (under tip options) **before** cards use.
6. After approval, the receipt prints automatically.

